ASSEMBLY INSTRUCTIONS | HOOK ATTACHMENT SET

(suitbale for Baso foam with a minimum thickness of 50 mm)

STEP 1 Position plug + hook centrally on Baso foam, press lightly and simultaneously turn approx. ¼ rotation to the LEFT (anti-clockwise).

STEP 2 Twist plug + hook to the RIGHT whilst pressing hard by hand (clockwise) approx. 3–4 rotations into Baso foam until the end of the plug is flush with Baso foam.

STEP 3 The Baso absorbers can now be hung on the hooks e. g. on taught steel rope or loops.

All specifications in these processing instructions are based on our current technical knowledge and experience. On account of the many possible which may occur during the processing and application of our products, these specifications do not exempt processors and users from carrying out their own checks and tests. A legally binding assurance of certain characteristics or suitability for a particular purpose cannot, however, be derived from these specifications. We reserve the right to make alterations, errors and fluctuations relating to the field;
SONATECH GmbH + Co. KG | Gutenbergstraße 10 | D-87781 Ungerhausen | Tel. +49 / (0)8393 / 922 12 - 0 | Fax +49 / (0)8393 / 922 12 - 20 | info@sonatech.de | www.sonatech.de
Issue: 02.02.2018